

NO.	ITEM NO	DESCRIPTION	Q'TY
1	RP9-01	MAIN HOUSING	1
		DEFLECTOR	1
		HOUSING INSERT	1
2	RP9-02	THINER WASHER_POM	1
3	RP9-03	LEVER ARM_ASM	1
4	RP9-04	THICKER WASHER_POM	1
5	RP9-05	NYLON NUT_5-40	1
6	RP9-06	DEFLECTOR KNOB	1
7	RP9-07	O-RING AS568-010-N70	1
8	RP9-08	DEFLECTOR CLIP	1
9	RP9-09	MOUTHPIECE_P8-GRAY	1
10	RP9-10	NYLON TIE	1
11	RP9-11	O-RING AS568-010-N70	1
12	RP9-12	ORIFICE	1
13	RP9-13	COUPLING	1
14	RP9-14	O-RING AS568-906-N70	1
15	RP9-15	LP SEAT	1
16	RP9-16	POPPET	1
17	RP9-17	MAIN SPRING	1
18	RP9-18	EXHAUST VALVE	1
19	RP9-19	EXHAUST COVER	1
20	RP9-20	DIAPHRAGM	1
21	RP9-21	O-RING AS568-015-N70	1
22	RP9-22	ADJUST TUBE	1
23	RP9-23	COVER RING	1
24	RP9-24B	PURGE COVER	1
25	RP9-25	ADJUST PISTON	1
26	RP9-26	ADJUSTMENT SPRING	1
27	RP9-27	ADJUST SCREW	1
28	RP9-28	O-RING AS568-010-N70	1
29	RP9-29	ADJUST SHIFT	1
30	RP9-30	ADJUST CAP SCREW	1
31	RP9-31	ADJUST KNOB	1
32	RP9-32	ADJUST LNOB SCREW	1
33	RP9-33	DECAL	1
34			
35			
36			
37			
38			

H2Odyssey RG-9P (RXL 2nd stage) Schematic

